

Grifftabelle für Tenor-(Sopran) Renaissance-Querflöte in d' Fingering Chart for Tenor-(Descant) Renaissance-Germanflute in D

nach Originalen in der Accademia Filarmonica di Verona, Design Neidhardt Bousset, Berlin
after originals in the Accademia Filarmonica di Verona, Design Neidhardt Bousset, Berlin

The image shows a musical staff with a treble clef and a key signature of one sharp (F#). The melody consists of 28 notes. Below the staff is a fingering chart with two rows: 'linke Hand' (left hand) and 'rechte Hand' (right hand). Each row contains 28 columns corresponding to the notes. The symbols used are solid black circles (●) for closed holes, open circles (○) for open holes, and the symbol ∅ for half-covered holes.

| | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|-------------|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| linke Hand | ● | ● | ● | ● | ● | ● | ● | ● | ● | ○ | ○ | ○ | ○ | ● | ● | ● | ● | ● | ● | ● | ● | ○ | ○ | ○ | ○ | ● | ● | ● | ● | ○ | ○ |
| rechte Hand | ● | ● | ● | ○ | ○ | ○ | ● | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |

- ○ Loch / Hole
- = offen / uncovered
- ∅ = halb geschlossen / half covered
- = geschlossen / covered